
TWO HEIGHTS OF YOUR NET

Tip to Tighten the Net


There is a kink in the bottom bar on both sides that has to be face up to tighten to the top part of the net.

AT PICKLEBALL HEIGHT


1.Unfold and connect all the poles to form the frame below.



2.Slide the net over the steel poles and rotate the two kinks facing upwards.




3.Height for Pickleball(3FT). During windy days you can put some weights on the base.




AT BADMINTON HEIGHT


1.If you want to use this net to play badminton, assemble the top poles.



2.Slide the net over the steel poles and rotate the two kinks facing upwards.



3.Height for Badminton(5FT). Put weights on the base if necessary.




RECOMMENDED COURT SIZE

Size of court is 17 feet wide and 34 feet long. Width and length can be increased or decreased proportionately depending on the area available. After determining the size, stick the landmark sticker on the ground along the net.

USERS INSTRUCTION

17FT PORTABLE PICKLEBALL NET SET



IMPORTANT SAFETY RULES

Read, Understand, and Follow all Instructions Carefully before Installing and using this Product

IMPORTANT SAFETY RULES

A WARNING!


- CHOKING HAZARD This item contains small parts. Not suitable for children under 3 years.
- This item is not a toy. Adult supervision is required at all times when the net is assembled and disassembled.
- Please Do Not climb, hang or lean on the net. The structure is not designed to support user body weight.
- Follow these rules to avoid serious injury or property damage.

STORAGE AND CARE

- After use, please disassemble the net and place all components back in the bag.
- For best results, store the bag indoors away from extreme temperatures and moisture.
- The handle accumulates sweat and dirt while in use, take the time to wipe it off with a towel or damp cloth after playing and keep it dry.

PARTS REFERENCE

NOTE: Please carefully inspect your new pickleball set to ensure all parts listed below are included. Before assembling, read all instructions and indentify all parts required for proper assembly. If you miss any parts please contact support@abovegenius.store



PARTS LIST

1	Net Frame Poles X 1 (Pre-connected by an elastic cord)	
2	Net X 1	
3	Racket X 4	
4	Pickleball X 4	
(5)	Court marker X 1	
6	Storage Bag X 1	